




Schurter



### CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S


□□□□□□ □□□□□□:  
 □□□□□□□□□□□□ / □□□□□□:  
 □■□□□□□□□□ □□□□□□■  
 □□□□□□□□□□ □□□□□□:  
 RoHS □□□□□□□□  
 □□□□□□□ □□□□□□□□□□□□□  
 □□□□□□□□□  
 □□□□□□□□□□□□□□ □□□

CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S  
 Schurter  
 SWITCH PUSHBUTTON SPST 100MA 42V  
 CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S.pdf  
 □□□□□□□ □□□□□□ / RoHS Compliant  
 6471 pcs stock  
 □□□□ □□□□□□  
 DHL/Fedex/TNT/UPS/EMS

□□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□□□□□□□□□□□  
 □□□□□□□□□□□□□□□□□□□□□□□□  
 □□□□□□□□□□□□□□□□□□□□□□□□  
 □□□□□□□□□□□□□□□□□□□□□□□□

#### □□□□□□□□□□□□□□□□ CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S













□□□□□□ □□□□□□	CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S
□□□□□□□□□□□□	Schurter
□□□□□□□	SWITCH PUSHBUTTON SPST 100MA 42V
□□□□□□□□ □□□□□□□□□□□□□□ / ROHS □□□□□□□□	□□□□□□□□ □□□□□□□□ / RoHS Compliant
□□□□□□□□□□ □□□□□□□□□□□□□□	6471 pcs
□□□□□□□□□□ □□□□□□□□	 CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S.pdf
□□□□□□□ □□□□□□□□□□ - DC	60V
□□□□□□□ □□□□□□□□□□ - AC	42V
□□□□□	Capacitive, Illuminated
□□□□□□□□□□ □□□□□□	Wire Leads
□□□□□□ □□□□□□□□	Off-On
□□□□□□	CPS
□□□□□□□□□□□□□□□□□□□□	Circular - 22.10mm Dia
□□□□□□□□□	Bulk
□□□□□□□□□□□□ □□□□□□□□□□□□	-40°C ~ 60°C
□□□□□□□□□□□□□□□□ □□□□	Panel Mount, Front
□□□□□□□□□□□□ □□□□□□□□□□□□□□□□□□□□ (MSL)	1 (Unlimited)
□□□□□□□□□□□□ □□□□□□□□□□	-
□□□□□□□□ □□□□□□□□□□ □□□□□□□□□□ / ROHS □□□□□□□□	Lead free / RoHS Compliant
□□□□□□□□□ □□□□□□□□	IP67 - Dust Tight, Waterproof
□□□□□□□□□□ □□□□□□□□□□□□□□□□□□□□□□	5 ~ 28 VDC
□□□□□□□□□□□ □□□□□□□□□□□□□□□□□□□□□□	LED, Green/Blue
□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□	Finger Guide, A Symbol
□□□□□□□□ □□□□□□□□□□□□□□□□□□□□□□□□	-
□□□□□□□□□ □□□□□□□□□□□□□□□□□□□□□□□□	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
□□□□□□□□□□ □□□□□□□□□□□□□□□□□□□□□□□□	100mA (AC/DC)
□□□□□ - ACTUATOR / CAP	Silver
□□□□	SPST
□□□□□□□□ □□□□□□□□□□	Round, Button, Flush

□□□□□□□□□□□□□□□□

#### Tags

Schurter CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S	CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S □□□□□□□□□□□□	CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S □□□□□□□□□□□□
CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S □□□□□	CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S □□□□□□□□□	CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S □□□□□□□□□□□□
CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S PDF Datasheet	CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S Download Datasheet	CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S Datasheet
CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S □□□□□□□□	□□□□□□□□□ CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S	□□□□□□□□□ Schurter CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S
Schurter CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S	Schurter □□□□□□□□□□□□	Schurter □□□□□□□□□□□□
Schurter CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S	Schurter Inc. CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1001-S	

□□□□□□□□ □□□□□□□□□□□□

 <p><b>CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W0000-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSHBUTTON SPST 100MA 42V                  □■□□□□□□□□□: 3188 pcs</p> <p><b>RFQ</b></p>	 <p><b>CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1073-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSHBUTTON SPST 100MA 42V                  □■□□□□□□□□□: 5378 pcs</p> <p><b>RFQ</b></p>
 <p><b>CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1077-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSHBUTTON SPST 100MA 42V                  □■□□□□□□□□□: 5244 pcs</p> <p><b>RFQ</b></p>	 <p><b>CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1004-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSHBUTTON SPST 100MA 42V                  □■□□□□□□□□□: 6271 pcs</p> <p><b>RFQ</b></p>
 <p><b>CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1076-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSHBUTTON SPST 100MA 42V                  □■□□□□□□□□□: 4610 pcs</p> <p><b>RFQ</b></p>	 <p><b>CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1003-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSHBUTTON SPST 100MA 42V                  □■□□□□□□□□□: 3244 pcs</p> <p><b>RFQ</b></p>
 <p><b>CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1002-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSHBUTTON SPST 100MA 42V                  □■□□□□□□□□□: 4568 pcs</p> <p><b>RFQ</b></p>	 <p><b>CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1074-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSHBUTTON SPST 100MA 42V                  □■□□□□□□□□□: 5031 pcs</p> <p><b>RFQ</b></p>
 <p><b>CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1006-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSHBUTTON SPST 100MA 42V                  □■□□□□□□□□□: 2980 pcs</p> <p><b>RFQ</b></p>	 <p><b>CPS22-LA00A10-SNCSNCWF-RI0CYVAR-W1075-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSHBUTTON SPST 100MA 42V                  □■□□□□□□□□□: 2811 pcs</p> <p><b>RFQ</b></p>
 <p><b>CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1005-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSHBUTTON SPST 100MA 42V                  □■□□□□□□□□□: 7023 pcs</p> <p><b>RFQ</b></p>	 <p><b>CPS22-LA00A10-SNCSNCWF-RI0GBVAR-W1007-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSHBUTTON SPST 100MA 42V                  □■□□□□□□□□□: 6230 pcs</p> <p><b>RFQ</b></p>

