

Schurter

### CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S

□□□□□□ □□□□□□: CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S  
 Schurter  
 SWITCH PUSH SPST-NC 100MA 42V  
 CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S.pdf  
 □□□□□□ □□□□□ / RoHS Compliant  
 4527 pcs stock  
 □□□□ □□□□□  
 DHL/Fedex/TNT/UPS/EMS

□□□□□□□□ □□□□□□□□

□□□□□□□□□□□□ □□□□□□□□ □□□□  
 □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□  
 □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□  
 □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□

### □□□□□□□□□□□□□□□□ CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S

□□□□□□ □□□□□□	CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S
□□□□□□□□□□□□	Schurter
□□□□□□□	SWITCH PUSH SPST-NC 100MA 42V
□□□□□□□□ □□□□□□□□□□□□□□□□ / ROHS □□□□□□□□	□□□□□□□□ □□□□□□□□ / RoHS Compliant
□□□□□□□□□□ □□□□□□□□□□□□□□□□	4527 pcs
□□□□□□□□□□ □□□□□□□□	CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S.pdf
□□□□□□□ □□□□□□□□□□ - DC	60V
□□□□□□□ □□□□□□□□□□ - AC	42V
□□□□□	Capacitive, Illuminated
□□□□□□□□□□ □□□□□□	Wire Leads
□□□□□□ □□□□□□□□	On-Mom
□□□□□□	CPS
□□□□□□□□ CUTOUT □□□□□□□□	Circular - 19.10mm Dia
□□□□□□□□	Bulk
□□□□□□□□□□ □□□□□□□□□□□□	-40°C ~ 60°C
□□□□□□□□□□ □□□□	Panel Mount, Front
□□□□□□□□□□ □□□□□□□□□□□□□□□□ □□□□□ (MSL)	1 (Unlimited)
□□□□□□□□□□ □□□□□□□□□□	-
□□□□□□□ □□□□□□□□□□ □□□□□□□□□□ / ROHS □□□□□□□□	Lead free / RoHS Compliant
□□□□□□□□ □□□□□□	IP67 - Dust Tight, Waterproof
□□□□□□□□□□ □□□□□□ (□□□□□□□□□□□□)	5 ~ 28 VDC
□□□□□□□□□□ □□□□□, □□□□□	LED, Cyan/Red
□□□□□□□□□□□□□□□□	ENTER Symbol
□□□□□□□□ □□□□□□□□□□	-
□□□□□□□□ □□□□□□□□	Pushbutton Switch SPST-NC Capacitive, Illuminated Panel Mount, Front
□□□□□□□□□□ □□□□□□□□□□	100mA (AC/DC)
□□□□□ - ACTUATOR / CAP	Silver
□□□□	SPST-NC
□□□□□□□□ □□□□	Round, Button, Flush

### □□□□□□□□□□□□□□□□

#### Tags

Schurter CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S	CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S □□□□□□□□□□□□	CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S □□□□□□□□□□□□
CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S □□□□□	CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S □□□□□□□□	CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S □□□□□□□□□□□□
CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S PDF Datasheet	CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S Download Datasheet	CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S Datasheet
CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S □□□□□□□□	□□□□□□□□ CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S	□□□□□□□□ Schurter CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S
Schurter CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S	Schurter □□□□□□□□□□□□	Schurter □□□□□□□□□□□□
Schurter CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S	Schurter Inc. CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1058-S	

### □□□□□□□□ □□□□□□□□□□□□

<p><b>CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1062-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSH SPST-NC 100MA 42V                  □■□□□□□□□□□: 5598 pcs</p> <p><b>RFQ</b></p>	<p><b>CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1061-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSH SPST-NC 100MA 42V                  □■□□□□□□□□□: 7075 pcs</p> <p><b>RFQ</b></p>
<p><b>CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1059-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSH SPST-NC 100MA 42V                  □■□□□□□□□□□: 3365 pcs</p> <p><b>RFQ</b></p>	<p><b>CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1053-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSH SPST-NC 100MA 42V                  □■□□□□□□□□□: 5090 pcs</p> <p><b>RFQ</b></p>
<p><b>CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1057-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSH SPST-NC 100MA 42V                  □■□□□□□□□□□: 6134 pcs</p> <p><b>RFQ</b></p>	<p><b>CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1056-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSH SPST-NC 100MA 42V                  □■□□□□□□□□□: 4725 pcs</p> <p><b>RFQ</b></p>
<p><b>CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1064-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSH SPST-NC 100MA 42V                  □■□□□□□□□□□: 4711 pcs</p> <p><b>RFQ</b></p>	<p><b>CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1054-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSH SPST-NC 100MA 42V                  □■□□□□□□□□□: 4558 pcs</p> <p><b>RFQ</b></p>
<p><b>CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1052-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSH SPST-NC 100MA 42V                  □■□□□□□□□□□: 3946 pcs</p> <p><b>RFQ</b></p>	<p><b>CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1060-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSH SPST-NC 100MA 42V                  □■□□□□□□□□□: 5059 pcs</p> <p><b>RFQ</b></p>
<p><b>CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1063-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSH SPST-NC 100MA 42V                  □■□□□□□□□□□: 3177 pcs</p> <p><b>RFQ</b></p>	<p><b>CPS19-NC00A10-SNCSNCNF-RIOCRVAR-W1055-S</b>                  □□□□□□□□□□□□: Schurter                  □□□□□□□: SWITCH PUSH SPST-NC 100MA 42V                  □■□□□□□□□□□: 4799 pcs</p> <p><b>RFQ</b></p>

