



95C05B4GWRT

□□□□□□ □□□□□□:
 □□□□□□□□□□□□ / □□□□□□:
 □■□□□□□□□□ □□□□□□■
 □□□□□□□□□□ □□□□□□□:
 RoHS □□□□□□□□
 □□□□□□□□ □□□□□□□□□□□□
 □□□□□□□□
 □□□□□□□□□□□□□□ □□□

95C05B4GWRT
 Grayhill, Inc.
 SWITCH TACTILE SPST-NO 0.05A 12V
 95C05B4GWRT.pdf
 □□□□□□□□ □□□□□□ / RoHS Compliant
 211281 pcs stock
 □□□□ □□□□□□
 DHL/Fedex/TNT/UPS/EMS



□□□□□□□□□□□□□□ □□□□□□□□ □□□□
 □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□
 □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□
 □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□□□ 95C05B4GWRT

□□□□□□ □□□□□□	95C05B4GWRT
□□□□□□□□□□□□	Grayhill, Inc.
□□□□□□□	SWITCH TACTILE SPST-NO 0.05A 12V
□□□□□□□□ □□□□□□□□□□□□ □□□□□□□□ / ROHS □□□□□□□□	□□□□□□□□ □□□□□□□□ / RoHS Compliant
□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□	211281 pcs
□□□□□□□□□□□□□□□□	95C05B4GWRT.pdf
□□□□□□□□□□□□□□□□	Gull Wing
□□□□□□□□ □□□□□□□□□□□□	0.25mm
□□□□□□□□ □□□□□□□□	Off-Mom
□□□□□□	95C
□□□□□□□□	Tape & Reel (TR)
□□□□□□□□□□□□	5.20mm x 5.20mm
□□□□□□□□□□□□ □□□□□□□□□□□□□□□□□□□□	-25°C ~ 70°C
□□□□□□□□□□□□□□□□□□□□	260gf
□□□□□□□□□□□□□□□□	Surface Mount
□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ (MSL)	1 (Unlimited)
□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□	200,000 Cycles
□□□□□□□□ □□□□□□□□□□□□□□□□□□□□□□□□ / ROHS □□□□□□□□	Lead free / RoHS Compliant
□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□	-
□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ (□□□□□□□□□□□□□□)	-
□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□	-
□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□	Non-Illuminated
□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□	Tactile Feedback
□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□	Tactile Switch SPST-NO Top Actuated Surface Mount
□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ @ □□□□□□	0.05A @ 12VDC
□□□□	SPST-NO
□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□	Standard
□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□	Top Actuated
□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□	Liquid Crystal Polymer (LCP)
ACTUATOR □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□	-
□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ PCB, □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□	1.49mm

□□□□□□□□□□□□□□□□

Tags

Grayhill, Inc. 95C05B4GWRT	95C05B4GWRT □□□□□□□□□□□□□□□□	95C05B4GWRT □□□□□□□□□□□□□□□□
95C05B4GWRT □□□□□	95C05B4GWRT □□□□□□□□□□	95C05B4GWRT □□□□□□□□□□□□□□□□
95C05B4GWRT PDF Datasheet	95C05B4GWRT Download Datasheet	95C05B4GWRT Datasheet
95C05B4GWRT □□□□□□□□	□□□□□□□□ 95C05B4GWRT	□□□□□□□□ Grayhill, Inc. 95C05B4GWRT
Grayhill, Inc. 95C05B4GWRT	Grayhill, Inc. □□□□□□□□□□□□	Grayhill, Inc. □□□□□□□□□□□□□□
Grayhill, Inc. 95C05B4GWRT	Grayhill Inc. 95C05B4GWRT	

□□□□□□□□ □□□□□□□□□□□□

<p>95C06A3GWRT □□□□□□□□□□□□□□□□: Grayhill, Inc. □□□□□□□□: SWITCH TACTILE SPST-NO 0.05A 12V □■□□□□□□□□: 367663 pcs</p> <p>RFQ</p>	<p>95C04B5T □□□□□□□□□□□□□□□□: Grayhill, Inc. □□□□□□□□: SWITCH TACTILE SPST-NO 0.05A 12V □■□□□□□□□□: 201814 pcs</p> <p>RFQ</p>
<p>95C04B5GWRT □□□□□□□□□□□□□□□□: Grayhill, Inc. □□□□□□□□: SWITCH TACTILE SPST-NO 0.05A 12V □■□□□□□□□□: 402974 pcs</p> <p>RFQ</p>	<p>95C05B2GWRT □□□□□□□□□□□□□□□□: Grayhill, Inc. □□□□□□□□: SWITCH TACTILE SPST-NO 0.05A 12V □■□□□□□□□□: 216673 pcs</p> <p>RFQ</p>
<p>95C06A3GWT □□□□□□□□□□□□□□□□: Grayhill, Inc. □□□□□□□□: SWITCH TACTILE SPST-NO 0.05A 12V □■□□□□□□□□: 171568 pcs</p> <p>RFQ</p>	<p>95C04B5GWT □□□□□□□□□□□□□□□□: Grayhill, Inc. □□□□□□□□: SWITCH TACTILE SPST-NO 0.05A 12V □■□□□□□□□□: 207245 pcs</p> <p>RFQ</p>
<p>95C06A2GWRT □□□□□□□□□□□□□□□□: Grayhill, Inc. □□□□□□□□: SWITCH TACTILE SPST-NO 0.05A 12V □■□□□□□□□□: 419152 pcs</p> <p>RFQ</p>	<p>95C06A2T □□□□□□□□□□□□□□□□: Grayhill, Inc. □□□□□□□□: SWITCH TACTILE SPST-NO 0.05A 12V □■□□□□□□□□: 611405 pcs</p> <p>RFQ</p>
<p>95C04B3T □□□□□□□□□□□□□□□□: Grayhill, Inc. □□□□□□□□: SWITCH TACTILE SPST-NO 0.05A 12V □■□□□□□□□□: 221404 pcs</p> <p>RFQ</p>	<p>95C06A2RAT □□□□□□□□□□□□□□□□: Grayhill, Inc. □□□□□□□□: SWITCH TACTILE SPST-NO 0.05A 12V □■□□□□□□□□: 282863 pcs</p> <p>RFQ</p>
<p>95C05B3GWRT □□□□□□□□□□□□□□□□: Grayhill, Inc. □□□□□□□□: SWITCH TACTILE SPST-NO 0.05A 12V □■□□□□□□□□: 89056 pcs</p> <p>RFQ</p>	<p>95C06A2GW □□□□□□□□□□□□□□□□: Grayhill, Inc. □□□□□□□□: SWITCH TACTILE SPST-NO 0.05A 12V □■□□□□□□□□: 139098 pcs</p> <p>RFQ</p>

