



Schurter

CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S

□□□□□ □□□□□□:
 □□□□□□□□□□□□□□ / □□□□□□:
 □■□■□■□■□■□■□■□
 □□□□□□□□□□ □□□□□□:
 RoHs □□□□□□□□
 □□□□□□□□□□□□□□□□□□
 □□□□□□□□
 □□□□□□□□□□□□□□□□

CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S
 Schurter
 SWITCH PUSH SPST-NO 100MA 42V
 CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S.pdf
 RoHS Compliant / RoHS Compliant
 2785 pcs stock
 □□□□ □□□□□□
 DHL/Fedex/TNT/UPS/EMS



□□□□□□□□□□□□□□□□ □□□□□
 □□□□□□□□□□□□□□□□□□□□□□□□
 □□□□□□□□□□□□□□□□□□□□□□□□
 □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□□□ CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S

| | |
|--|--|
| □□□□□□ □□□□□□ | CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S |
| □□□□□□□□□□□□□□ | Schurter |
| □□□□□□□ | SWITCH PUSH SPST-NO 100MA 42V |
| □□□□□□□□ □□□□□□□□□□ □□□□□□□□ / ROHS □□□□□□□□ | □□□□□□□□ □□□□□□□□ / RoHS Compliant |
| □□□□□□□□□□ □□□□□□□□□□□□□□ | 2785 pcs |
| □□□□□□□□□□ □□□□□□□□□□ | CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S.pdf |
| □□□□□□ □□□□□□□□□□ - DC | 60V |
| □□□□□□ □□□□□□□□□□ - AC | 42V |
| □□□□□ | Capacitive, Illuminated |
| □□□□□□□□□□ □□□□□□ | Wire Leads |
| □□□□□□ □□□□□□□□ | Off-Mom |
| □□□□□□ | CPS |
| □□□□□□ CUTOUT □□□□□□□□ | Circular - 16.10mm Dia |
| □□□□□□□□ | Bulk |
| □□□□□□□□□□ □□□□□□□□□□□□ | -40°C ~ 60°C |
| □□□□□□□□□□□ □□□□ | Panel Mount, Front |
| □□□□□□□□□□□ □□□□□□□□□□□□ □□□□ (MSL) | 1 (Unlimited) |
| □□□□□□□□□□□ □□□□□□□□□□ | - |
| □□□□□□□ □□□□□□□□□□ □□□□□□□□ / ROHS □□□□□□□□ | Lead free / RoHS Compliant |
| □□□□□□□□ □□□□□□ | IP67 - Dust Tight, Waterproof |
| □□□□□□□□□ □□□□□□ (□□□□□□□□□□□□) | 5 ~ 28 VDC |
| □□□□□□□□□□ □□□□□, □□□□□ | LED, Blue/White |
| □□□□□□□□□□□□□□□□□□ | Finger Guide, OFF Symbol |
| □□□□□□□□ □□□□□□□□□□ | - |
| □□□□□□□□□ □□□□□□□□ | Pushbutton Switch SPST-NO Capacitive, Illuminated Panel Mount, Front |
| □□□□□□□□□□ □□□□□□□□□□ | 100mA (AC/DC) |
| □□□□□ - ACTUATOR / CAP | Silver |
| □□□□ | SPST-NO |
| □□□□□□□□ □□□□ | Round, Button, Flush |

□□□□□□□□□□□□□□

Tags

| | | |
|---|--|---|
| Schurter CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S | CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S □□□□□□□□□□□□□□ | CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S □□□□□□□□□□□□□□ |
| CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S □□□□ | CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S □□□□□□□□□□ | CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S □□□□□□□□□□□□□□ |
| CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S PDF Datasheet | CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S Download Datasheet | CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S Datasheet |
| CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S □□□□□□□□ | □□□□□□□□□□ CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S | □□□□□□□□□□ Schurter CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S |
| Schurter CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S | Schurter □□□□□□□□□□□□□□ | Schurter □□□□□□□□□□□□□□ |
| Schurter CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S | Schurter Inc. CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1066-S | |

□□□□□□□□ □□□□□□□□□□□□

| | |
|--|--|
| <p>CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1072-S □□□□□□□□□□□□□□: Schurter □□□□□□□: SWITCH PUSH SPST-NO 100MA 42V □■□■□■□■□■□■□■□■□■□ : 5099 pcs</p> <p style="text-align: center;">RFQ</p> | <p>CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1064-S □□□□□□□□□□□□□□: Schurter □□□□□□□: SWITCH PUSH SPST-NO 100MA 42V □■□■□■□■□■□■□■□■□■□ : 5132 pcs</p> <p style="text-align: center;">RFQ</p> |
| <p>CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1060-S □□□□□□□□□□□□□□: Schurter □□□□□□□: SWITCH PUSH SPST-NO 100MA 42V □■□■□■□■□■□■□■□■□■□ : 3329 pcs</p> <p style="text-align: center;">RFQ</p> | <p>CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1061-S □□□□□□□□□□□□□□: Schurter □□□□□□□: SWITCH PUSH SPST-NO 100MA 42V □■□■□■□■□■□■□■□■□■□ : 6752 pcs</p> <p style="text-align: center;">RFQ</p> |
| <p>CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1069-S □□□□□□□□□□□□□□: Schurter □□□□□□□: SWITCH PUSH SPST-NO 100MA 42V □■□■□■□■□■□■□■□■□■□ : 3720 pcs</p> <p style="text-align: center;">RFQ</p> | <p>CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1068-S □□□□□□□□□□□□□□: Schurter □□□□□□□: SWITCH PUSH SPST-NO 100MA 42V □■□■□■□■□■□■□■□■□■□ : 3087 pcs</p> <p style="text-align: center;">RFQ</p> |
| <p>CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1070-S □□□□□□□□□□□□□□: Schurter □□□□□□□: SWITCH PUSH SPST-NO 100MA 42V □■□■□■□■□■□■□■□■□■□ : 4754 pcs</p> <p style="text-align: center;">RFQ</p> | <p>CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1063-S □□□□□□□□□□□□□□: Schurter □□□□□□□: SWITCH PUSH SPST-NO 100MA 42V □■□■□■□■□■□■□■□■□■□ : 3742 pcs</p> <p style="text-align: center;">RFQ</p> |
| <p>CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1067-S □□□□□□□□□□□□□□: Schurter □□□□□□□: SWITCH PUSH SPST-NO 100MA 42V □■□■□■□■□■□■□■□■□■□ : 3520 pcs</p> <p style="text-align: center;">RFQ</p> | <p>CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1062-S □□□□□□□□□□□□□□: Schurter □□□□□□□: SWITCH PUSH SPST-NO 100MA 42V □■□■□■□■□■□■□■□■□■□ : 6607 pcs</p> <p style="text-align: center;">RFQ</p> |
| <p>CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1071-S □□□□□□□□□□□□□□: Schurter □□□□□□□: SWITCH PUSH SPST-NO 100MA 42V □■□■□■□■□■□■□■□■□■□ : 6552 pcs</p> <p style="text-align: center;">RFQ</p> | <p>CPS16-NO00A10-SNCSNCWF-RI0BWVAR-W1065-S □□□□□□□□□□□□□□: Schurter □□□□□□□: SWITCH PUSH SPST-NO 100MA 42V □■□■□■□■□■□■□■□■□■□ : 5588 pcs</p> <p style="text-align: center;">RFQ</p> |

