

Schurter
ELECTRONIC COMPONE

CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1028-S

CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1028-S
Schurter
SWITCH PUSHBUTTON SPST 100MA 42V
CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1028-S.pdf
RoHS Compliant
3021 pcs stock
DHL/Fedex/TNT/UPS/EMS

RFQ (Redacted)

Product description and availability information (partially obscured).

CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1028-S	
Manufacturer	Schurter
Part	SWITCH PUSHBUTTON SPST 100MA 42V
RoHS / Compliance	RoHS Compliant
Stock	3021 pcs
Data Sheet	CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1028-S.pdf
DC Voltage	60V
AC Voltage	42V
Operation	Capacitive, Illuminated
Mounting	Wire Leads
Switching	Off-On
Configuration	CPS
Mounting Style	Circular - 19.10mm Dia
Quantity	Bulk
Temperature	-40°C ~ 60°C
Mounting Position	Panel Mount, Front
MSL (Max Solderability Limit)	1 (Unlimited)
RoHS	-
RoHS / Compliance	Lead free / RoHS Compliant
Protection	IP67 - Dust Tight, Waterproof
Voltage Range	5 ~ 28 VDC
LED Color	LED, Magenta/White
Features	Finger Guide, 1 Symbol
Material	-
Series	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
Current	100mA (AC/DC)
Material (Actuator)	Silver
Switching	SPST
Form	Round, Button, Flush

Tags

Tags

Schurter CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1028-S	CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1028-S	CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1028-S
CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1028-S	CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1028-S	CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1028-S
CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1028-S PDF Datasheet	CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1028-S Download Datasheet	CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1028-S Datasheet
CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1028-S	□□□□□□ CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1028-S	□□□□□□ Schurter CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1028-S
Schurter CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1028-S	Schurter □□□□□□□□□□	Schurter □□□□□□□□□□
Schurter CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1028-S	Schurter Inc. CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1028-S	

RFQ

CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1025-S Schurter SWITCH PUSHBUTTON SPST 100MA 42V 4559 pcs RFQ	CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1032-S Schurter SWITCH PUSHBUTTON SPST 100MA 42V 3276 pcs RFQ
CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1034-S Schurter SWITCH PUSHBUTTON SPST 100MA 42V 3538 pcs RFQ	CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1030-S Schurter SWITCH PUSHBUTTON SPST 100MA 42V 6914 pcs RFQ
CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1024-S Schurter SWITCH PUSHBUTTON SPST 100MA 42V 5958 pcs RFQ	CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1029-S Schurter SWITCH PUSHBUTTON SPST 100MA 42V 6463 pcs RFQ
CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1027-S Schurter SWITCH PUSHBUTTON SPST 100MA 42V 2842 pcs RFQ	CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1026-S Schurter SWITCH PUSHBUTTON SPST 100MA 42V 5402 pcs RFQ
CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1031-S Schurter SWITCH PUSHBUTTON SPST 100MA 42V 5234 pcs RFQ	CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1022-S Schurter SWITCH PUSHBUTTON SPST 100MA 42V 5835 pcs RFQ
CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1023-S Schurter SWITCH PUSHBUTTON SPST 100MA 42V 3658 pcs RFQ	CPS19-LA00A10-SNCSNCWF-RIOMWVAR-W1033-S Schurter SWITCH PUSHBUTTON SPST 100MA 42V 3463 pcs RFQ

